



User Manual

Wine Cooler

Cantina

IMPORTANT SAFETY INSTRUCTIONS

WARNING

To reduce the risk of fire, electrical shock or injury when using your appliance, follow these basic precautions

- ❖ Read all instructions before using the Wine Cooler
- ❖ **DANGER or WARNING:** Risk of child entrapment
Child entrapment and suffocation are not problems of the past. Junked or abandoned appliances are still dangerous.... even if they will "just sit in the garage a few days"
- ❖ **Before you throw away your old Wine Cooler:** Take off the door, Leave the shelves in place so that children may not climb inside easily.
- ❖ **Never allow children** to operate, play with or crawl inside the appliance.
- ❖ Never clean appliance parts with flammable fluids. The fumes can create a fire hazard or explosion.
- ❖ Do not store or use gasoline or any other flammable vapours and liquids in the vicinity of this or any other appliance. The fumes can cause a fire hazard or explosion.
- ❖ Do not store or use gasoline or any other flammable vapours and liquids in the vicinity of this or any other appliance. The fumes can cause a fire hazard or explosion.
- ❖ Do not use electrical appliances inside the appliance.
- ❖ Do not damage the refrigerant circuit pipes.
- ❖ Do not allow open flames or ignition sources to enter the appliance. When transporting and cleaning the appliance ensure that the refrigerant circuit is not damaged. In the event of damage, make sure that there are no ignition sources nearby and keep the room well ventilated.

INSTALLATION INSTRUCTIONS

➤ **Before using your Wine Cooler**

Remove the exterior and interior packing materials.

Before connecting the Wine Cooler to the power source, let it stand upright with open doors for approximately 2 hours. This will reduce the possibility of a malfunction in the cooling system due to handling during transportation.

Clean the interior surface with lukewarm water using a soft cloth.

➤ **Installation of your Wine Cooler**

This appliance is designed to be for free standing or built-in (fully recesses) installation. Place your Wine Cooler on a surface floor which is strong enough to support it when fully loaded. To level your Wine Cooler, adjust the front levelling leg at the bottom of the Wine Cooler.

Standard EN 378 specifies that the room in which you install your appliance must have a volume of 1 m³per 8g of R600a refrigerant used in the appliance, so as to avoid the formation of inflammable gas/air mixture in the room where the appliance is located in the event of a leak in the refrigerant circuit. The quantity of the refrigerant used in your appliance is indicated on the type plate on the inside of the appliance.

Locate the Wine Cooler away from direct sunlight and sources of heat (stove, heater, radiator, etc.) Direct sunlight may affect the acrylic coating and heat sources may increase electrical consumption. Extreme cold ambient temperatures may also cause the unit not to perform properly.

Avoid locating the appliance in damp areas.

Plug the Wine Cooler into an exclusive, properly installed grounded wall outlet. Any questions concerning power and grounding should be directed to a certified electrician or an authorised product service centre.

OPERATING YOUR WINE COOLER

The Wine Cooler should be placed in where the ambient temperature is between 32-95 degrees Fahrenheit (0-35°C). If the ambient temperature is above or below this range, the performance of the unit may be affected. For example, placing your unit in extreme hot or cold conditions may cause interior temperatures to fluctuate. The range of 40-65 degrees Fahrenheit (5-18°C) may not be reached.

Recommended temperatures for Wine Cooling

Red Wines	58-65°F (15-18°C)
Dry/white wines	48-57°F (9-15°C)
Sparkling wines	40-47°F (5-9°C)

➤ **ON/OFF power**

To turn the appliance ON or OFF, press the POWER button.

➤ **Setting the temperature controls**

Each cooling compartment of the Wine Cooler (upper and lower) is independently controlled. To set the temperature:

Connect the power cord to a properly grounded outlet. In the event of a power interruption, all previous temperature settings are automatically erased and each compartment will default to a preset temperature.

You can set the temperature for each compartment by pushing the SET UPPER or SET LOWER button. Each depression of the buttons will scroll through the available temperature settings (for each compartment) in increments of 1 degree.

When you store mostly red wines, the temperature you control by pushing the button, needs to be set at between 58-65°F (15-18°C).

When you store mostly white wines, the temperature needs to be set at between 48-57°F (9-15°C).

When you store mostly sparkling wines, the temperature needs to be set at between 40-70°F (5-9°C).

You can select temperature display setting from Fahrenheit to Celsius degree by pushing the SET UPPER and SET LOWER button at the same time for 5 seconds.

Upper compartment: The temperature setting can be adjusted from 41°F to 64°F (5°C-18°C)

Lower compartment: The temperature setting can be adjusted from 41°F to 64°F (5°C-18°C)

NOTE: If the unit is unplugged, power lost, or turned off, you must wait 3 to 5 minutes before re-starting the appliance. If you attempt to start before this time delay the Wine Cooler will not start.

When you use the Wine Cooler for the first time or restart the Wine Cooler after having been shut off for a long time, let the unit run for at least 8h to get the desired temperature.

➤ **Interior Light**

You can turn the interior light ON or OFF by pushing the LIGHT button.

CARE AND MAINTENANCE

➤ **Cleaning your Wine Cooler**

Turn off the power, unplug the appliance and remove all items, including shelves and rack. Wash the inside surfaces with warm water and baking soda solution. The solution should be about two tablespoons of baking soda to a quart of water.

Wash the shelves with a mild detergent solution.

Please note that, as can happen with other forms of storage, slight mould may form depending on the type of adhesive on the label of the bottles. This can be rectified by carefully cleaning any adhesive residues off the bottles.

Wring excess water out of the sponge or cloth when cleaning the area of controls or any electrical parts.

Wash the outside cabinet with lukewarm water and a mild detergent. Rinse well and wipe dry with a soft clean cloth.

➤ **Power failure**

Most power failures are corrected within a few hours and should not affect the temperature of your appliance, if you minimize the number of times the door is opened. If the power is going to be off for a longer period of time, you need to take the proper steps to protect the contents.

➤ **Vacation time**

Short vacations: leave the Wine Cooler operating during vacations of less than 3 weeks.

Long vacations: If the appliance will not be used for several month, remove all items and turn off the appliance. Clean and dry the interior thoroughly. To prevent odour or mould growth, leave door ajar, blocking it open, if necessary.

➤ **Moving your Wine Cooler**

- Remove all items
- Securely tape down all loose items, such as shelves, inside your appliance
- Turn the adjustable leg up to the base to avoid damage
- Tape the door shut
- Be sure the appliance stays secure in the upright position during transport. Also protect outside of appliance with a blanket or something similar.

➤ **Energy saving tips**

The Wine Cooler should be located in the coolest area of the room, away from heat producing appliances or direct sunlight.

PROBLEMS WITH YOUR WINE COOLER ??

You can solve many common Wine Cooler problems easily, saving you the cost of a possible service call. Try the suggestions below to see if you can solve the problem before calling the service technician.

TROUBLE SHOOTING GUIDE

PROBLEM	POSSIBLE CAUSE
Wine Cooler does not operate	Not plugged in The appliance is turned OFF The circuit breaker tripped or blown fuse
Wine Cooler is not cold enough	Check the temperature control setting External environment may require a higher setting. The door is opened too often. The door is not closed completely The temperature control is not set correctly. The door gasket does not seal properly The fan outlet is blocked by objects (Air can not ventilate inside the unit)
Turns on and off frequently	The room temperature is hotter than normal. A large amount of contents has been added to the Wine Cooler The door is opened too often. The door is not closed completely. The temperature control is not set correctly. The door gasket does not seal properly.
Vibrations	Check to assure that the Wine Cooler is level.
The Wine Cooler seems to make too much noise	The rattling noise may come from the flow of the refrigerant, which is normal. As each cycle ends, you may hear gurgling sounds caused by the flow of refrigerant in your Wine Cooler. Contraction and expansion of the inside walls may cause popping and crackling noises. The Wine Cooler is not level.
The door will not close properly	The Wine Cooler is not level. The gasket is dirty The shelves are out of position.

DISPOSAL NOTES

This packaging is made of recyclable materials.

Please return the packaging material to an official collection point.

Ensure that the refrigerant circuit is not damaged when the appliance that is no longer needed is taken away for disposal.

Details of the refrigerant used can be found on the type plate.

Appliances which are no longer needed must be disposed of in a professional and appropriate way, in accordance with the current local regulation and law.